

Installation instructions for overlapping edges:

Just follow these 4 simple steps to install our 24" x 48" Overlapping Edge Decorative Ceiling System to most any clean hard smooth surface. It is really quick and easy.

1) Prepare the Surface Ceiling tiles and Plan & Test Installation:

The PVC Ceiling Tiles can be installed on any hard plain smooth clean surface. In fact some customers have installed over existing Popcorn Ceiling. Install by locating center of the room or installation surface or Draw an angle and draw straight lines in the corner (in width and length part) and make a 90 degree angle, for the starting point of pasting

A Clean Surface is necessary so be sure to wipe off the ceiling or other surface you are installing the tiles over and make it smooth and even. Remove loose plaster, paint, wall paper, and any oily residue etc. Draw a chalk line in the middle of the room (preferably through the light fixture electrical box). Select preferred adhesive, tape measure, straight edge, scissors, and box cutter, cleaning cloth or moist sponge

We recommend that all customers always test the application and allow it to rest at least 24 hours to evaluate the process and results to make an informed decision as whether the application is right for your particular scenario.

2) Apply the adhesive:

Apply any good quality urethane or rubber based adhesive only on the edges and raised portions of the PVC Ceiling Tile we recommend Contact Cement Gel by DAP Weldwood Original Formula or Loctite All Purpose Construction Adhesive to the back of the tile. If using Contact Cement we suggest you let it dry until adhesive solvents evaporate. Please check the drying time on the pack of the adhesive, usually it is anywhere between 2-5 minutes. Applying the adhesive on the ceiling also will improve bonding and strength. Approximately, 2 gallon of adhesive will be enough to cover 75 tiles or 600 square feet when used on both, the tiles and the ceiling.

3) Place & Press:

Place the sheet in the required position (first sheet at the 90 degree point if that is your desired installation method) and press firmly but gently. Overlap the edges with the previous sheet and press firmly with fingertips using gentle pressure. After completing first straight row work your way to the sides. Exercise caution not to get adhesive on fingers or onto the ceiling tiles.

4) Special notice:

The use of Contact Cement adhesive can easily get on the fingers and then on the ceiling tiles. These smudges of adhesive can be difficult to clean and the solvent used to clean can distort the Paint Color of the Tile.

CONGRADULATIONS – YOU NOW HAVE A BEAUTIFUL DECORATIVE CEILING!